

CONTACT

HEAD OFFICE BHOPAL

13-A & 12-D - Sector-D Industrial Area,Govindpura, Bhopal – 462 023, India. Tel: 0755-4233535(30 Lines) 26062661/662 Fax: 0755-4270730,

sanfield@sanfieldindia.in

DELHI OFFICE

B-7, 2nd Floor, South Extension - II, New Delhi - 110 049 Tel: 011- 46026903 sanfielddelhi@sanfieldindia.in_

MUMBAI OFFICE

Hind Saurastra Industrial Co-op.
Society Ltd.
Unit No. B-17, Marol Naka,
Andheri Kurla Road,
Andheri (E) Mumbai - 400059
Tel.: 022-28500275/276
sanfieldmumbai@sanfieldindia.in

·		
AHMEDABAD	BANGALORE	CHENNAI
ieldahmedabad@sanfieldindia.in +918980314418	sanfieldbangalore@sanfieldindia.in +9180500 10502	sanfieldchennai@sanfieldindia.in +919840165062

HYDERABAD sanfieldhyderabad@sanfieldindia.in +919977271110

PUNE

sanfieldpune@sanfieldindia.in +91 7722089602








www.sanfieldindia.in



SIL GROUT-IT

Sanfield GROUT-IT provides an economic, effective solution for design of precast elements in Construction. Precast concrete construction is gaining popularity worldwide, The same is because of faster turnaround time and precise executions. GROUT-IT compliments this need.


Sanfield is a Leading construction solution provider, We have developed GROUT-IT system to create rebar continuity between precast concrete elements.




GROUT-IT coupler is designed to connect wall or column precast elements either horizontally and vertically.

In horizontal applications, and in vertical applications with the GROUT-IT coupler installed in the top element, the connection is achieved by injecting the GROUT-IT through the inlet pipe.

In vertical applications with the GROUT-IT coupler installed in the bottom element, the GROUT-IT can simply be poured by gravity directly into the coupler cavity.



Installing GROUT-IT



Close the formwork and cast the concrete. after formwork removal, remove the plastic caps from the couplers. Bring the pre-cast element to site. Check that the bars protruding from the previous element are long enough.

Insert the new element over the previous one.

Inject the GROUT-IT until it comes out of the air vents.
Put the plugs back in place after finishing each injection.