
Sanfield Ecobox System is a smart and easy to install method of maintaining continuity of reinforcement at construction joints in concrete. It consists of a galvanised steel casing and pre-bent bars that are housed within the casing and are enclosed by a protective cover.

ADVANTAGES OF ECOBOX

- Unique shape guarantees a tongue and groove connection between the two concreting phases.
- The edges on the sides prevent displacement of the casing when the lid is removed, improving the quality of the anchoring.
- Cardboard inserts, perfectly adapts to the shape of the casing, preventing the penetration of cement slurry along the sides of the casing.
- More safe installation supported by the cardboard lid (no more hand cutting).
- No unfriendly waste of material.
- Ecobox saves costs, time and eventually money.

ADVANTAGES OF COUPLER BOX

- Unique Solution for future Coupler Reinforcement
- Smart work suitable for Slip & Jump Form works
- Ideal for precast connecting structures.




The lengths of the steel casings are 1.20 and 2.40Mtr. respectively.

The standard measurements of the stirrups are shown below.

(Dimensions A and B) are available to order.

- The two commercial* standard length of Ecobox are 1.20 and 2.4 Mtr respectively.
- The width of the casing depends on the type of casing suitable to slab width
- The height of the metal casing is 30 mm approx



INSTALLATION PROCEDURE


1.Check that the chosen dimensions of the Ecobox correspond with the required concrete cover of the second concreting phase. Ensure that the thermocol inserts are in.




<u>2.</u>Fix the Ecobox to the form work or to the Reinforcements, if not nailed to formwork.



3. Cast the concrete in the first phase.




<u>4.</u>Remove the cardboard lid after removing the form work.



<u>5</u>.Check that the stirrups are completely clean.




<u>6.</u>Bend the bars out. It is advisable to use a bending tool to avoid distortion of bayonet.



CENTERING OF ECOBOX

- The Ecobox can cope with a curve because of the saw cuts on the sides of the casing.
- Obviously the starter bars should not be cut or damaged.
- The openings in the casing must be carefully sealed before the Concrete is cast.






"The only rebar casing which can realise a tongue and groove connection between the two concreting phases."


STANDARD TYPES AND DIMENSION

S TYPE



S Type Ecobox in development length of bar for spacing.


Type of Eco Box(X)	Steel Diameters mm.	Maximum Development length of Bar(C) for spacing (E)					
		100	150	200	240	300	
45 S	6			1000	1100	1100	
	8		500	700	800	1000	
	10		390	500	600		
60 S	8		800	1000	1100		
	10		700	800			
90 S	10	600	900	1050			
	12	480	700	950			



D Type Ecobox in development length of bar for spacing.

for spacing.						
Type of Eco Box(X)	Steel Diameters mm.	Maximum Development length of Bar(C) for spacing (E)				
		100	150	200	240	300
	6		750	800	900	1000
90D	8		450	600	700	800
	10		390	500		
120D	6		800	1000	1100	
	8		500	600	750	1000
	10		400	650		
	6		1200	1200		
160D	8		900	1100		
1000	10		700	800		
	12		600	750		
190D	8		600	600		
	10		600	600		
	12		600	600		
230D	8		600			
	10		600	600		
	12		600			






DS Type Ecobox in development length of bar for spacing.

Type of Eco	Steel Diameters mm.	Maximum Development length of Bar(C) for spacing (E)					
Box(X)		100	150	200	240	300	
120DS	8		600	600			
	10		600	600			
	12	310	480	640			
160DS	8		600	600			
	10		600	600			
	12	480	600	600			
190DS	8		600	600			
	10		600	600			
	12	600	600	600			
230DS	8		600	600			
	10		600	600			
	12	600	600	600			

DX TYPE



DX Type Ecobox in development length of bar for spacing

Type of Eco Box(X)	Steel Diameters mm.	Maximum Development length of Bar(C) for spacing (E)					
		100	150	200	240	300	
45 DX	6			1000	1100		
	8		500	700	800		
	10		390	500			
60 DX	8		800	1000	1100		
	10		700	800			

Sanfield [India] Limited.



MUMBAI OFFICE

BHOPAL (Head Office)

Hind Saurastra Industrial Co-op. Society Ltd, Unit No.b-17 Marol Naka Andheri Kurla Road, Andheri (e), mumbai-400059 Tel: 022-28500275/276

13-A & 12-D - Sector-d Industrial Area, Govindpura, Bhopal - 462 023, India. Tel: 0755-4233535(30 Lines) 26062661/662 Fax: 0755-4270730,

B-7, 2nd Floor, South Extension - II, New Delhi - 110 049 Tel: 011-46026903 sanfielddelhi@sanfieldindia.in

sanfield@sanfieldindia.in

sanfieldmumbai@sanfieldindia.in AHMEDABAD CHENNAI HYDERABAD BANGALORE sanfieldahmedabad@sanfieldindia.in sanfieldchennai@sanfieldindia.in sanfieldhyderabad@sanfieldindia.in sanfieldbangalore@sanfieldindia.in +918980314418 +919840165062 +919977271110 +9180500 10502

SANFIELD

SMART REINFORCEMENT

CONNECTIONS



ECOBOX & COUPLER BOX.

Sanfield [India] Limited.

